

DRIVE SHOES

DRIVE SHOES

421 DRIVE SHOES

Features:

- 1/2 of shoe heat treated to 48-54 Rockwell "C" - hardness tested
- Highest quality seamless steel tube (to A.P.I. specs)
- Concentric machining assures straight setting in well
- Inside bevel on cable styled shoes radiused to allow drilling tools to be easily pulled back through shoe
- Zinc phosphate coated and painted to enhance appearance and corrosion-resistance

Cable Tool Style - Threaded - Model 421T

Part Number	Casing Nominal	Casing O.D.	Shoe O.D.	Shoe I.D.	Shoe Length	Thread Type	List Price Each
941274	2	2 3/8	2.875	2 3/32	3	11 1/2 NPS	See separate price list
941285	4	4 1/2	5.000	4 1/16	4	8 NPS	
941287	5	5 9/16	6.050	5 3/32	4 1/2	8 NPS	
941289	6	6 5/8	7.390	6 1/8	5 1/2	8 NPS	



Cable Tool Style - Weld On - Model 421W

941318	4	4 1/2	5.000	4 1/16	4	—	See separate price list
941320	5	5 9/16	6.050	5 3/32	4 1/2	—	
941322	6	6 5/8	7.390	6 1/8	5 1/2	—	
941370	6 1/4	6 5/8	7.390	6 9/32	5 1/2	—	
941325	8	8 5/8	9.625	8 1/8	8	—	
941328	10	10 3/4	11.750	10 1/4	10	—	
941331	12	12 3/4	14.000	12 5/32	12	—	
941405	6	6 5/8	7.390	6 1/8	4 (midget)	—	

Rotary Style - Threaded - Model 421RT

941378	2	2 3/8	2.875	2 3/32	3	11 1/2 NPS	See separate price list
941383	4	4 1/2	5.000	4 1/16	4 1/2	8 NPS	
941385	5	5 9/16	6.050	5 3/32	4 1/2	8 NPS	
941387	10	10 3/4	11.750	10 1/4	10	8 NPS	
941388	6	6 5/8	7.390	6 1/8	5 1/2	8 NPS	
941403	6	6 5/8	7.390	6 1/8	4 (midget)	8 NPS	



Rotary Style - Weld On - Model 421RW

941393	4	4 1/2	5.000	4 1/16	4	—	See separate price list
941394	5	5 9/16	6.050	5 3/32	4 1/2	—	
941391	6	6 5/8	7.390	6 1/8	5 1/2	—	
941400	6 1/4	6 5/8	7.390	6 9/32	6	—	
941407	6	6 5/8	7.390	6 1/8	4 (midget)	—	